



# COLUMN & POST™

## Round Bracket Kit Installation Instruction (Includes 3 brackets, 6 screws)

1. Place each bracket approximately 1/3 of the way around the column.
2. Use construction adhesive (not included) to adhere the bracket to the column.
3. Drill 5/32" pilot holes through the bracket into the substrate.
4. Fasten bracket with the supplied screws.

*\* Brackets are not a wind uplift device.*

