



Square Bracket Kit Installation Instruction (Includes 2 brackets, 4 screws)

1. Place each bracket on opposing corners at bottom of post.
2. Use construction adhesive (not included) to adhere the bracket to the post.
3. Drill 5/32" pilot holes through the bracket into the substrate.
4. Fasten bracket with the supplied screws.

** Brackets are not a wind uplift device.*

